

R106 R112 R113 R115 R117 R118 R120 R121

ON GDH04

ON GDH04

ON

OFF

GF  
ITRM  
OTRM  
GP\_1  
GP\_2  
GP\_3  
GP\_4  
TTL

General-purpose

Multicast  
address

MULTICAST ADDR

ON GDH04

ON

OFF