

WRPC

Aux WB
Master

aux_cyc_o
aux_stb_o
aux_we_o
aux_sel_o
aux_adr_o
aux_dat_o
aux_ack_i
aux_err_i
aux_stall_i

Ext WB
Slave

wb_cyc_i
wb_stb_i
wb_we_i
wb_sel_i
wb_adr_i
wb_dat_i
wb_ack_o
wb_err_o
wb_stall_o

WB Slave

Module
controlled
from
WRPC

WB Master

Module
maintaining
WRPC

